

SkuttleTightTM

All-In-One Attic Entry System!!

Installation Instructions for Model ST-200SW

- 1- Frame rough opening 22-1/2" X 30". Use a 2x8 for the bottom and a 2x4 or 2x6 for the top. Make sure hole is plumb and level.
- 2- Install insulation, Vapor Barrier and drywall to the wall. Cut out hole where rough opening is located.
- 3- Remove ST-200SW from box and slide into R.O. making sure the bottom is sitting on the 2x8. Level, Plumb, Square as needed. Check reveal around door to frame. Nail taping Flange with 1-5/8" drywall nails at 8" O.C.
- 4- Turn both latches clockwise and slide the door into the attic. Install 2-1/2" drywall screw in pre drilled holes. Making sure not to over tighten.
- 5- Apply a bead of high quality acrylic caulking where the frame and rough opening meet on the attic side.
- 6- Reinstall door, turn latches counter clockwise to latch. Double check fit and margins.
- 7- Drywall tape and compound the taping flange (like a corner bead). Texture and paint as desired.

These short and simple instruction are designed for Professional Installation, if you need further help please feel free to call

1-866-758-8853